

Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure & Temperature	Pressure & Temperature	1/8" -27 NPTF
2 – Air Intake Restriction	Pressure	1/8" -27 NPTF
3 – Fuel Inlet Restriction	Pressure	3/8" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	1/2" UNS 2B
5 – Coolant Pump Inlet Pressure & Temperature	Pressure & Temperature	M18 x 1.5*
5 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	¼"-18 NPT
6 – Sea Water Return Temperature	Pressure & Temperature	½"-14 NPTF (anode location)

<sup>\*</sup> If port is utilized for coolant return this parameter cannot be checked. A port will be added to the coolant tube in the future to check this parameter.