



Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure & Temperature	Pressure & Temperature	1/8" -27 NPTF
2 – Air Intake Restriction	Pressure & Temperature	1/8" -27 NPTF
3 – Fuel Inlet Restriction	Pressure	1/2" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	3/8" ORFS
5 – Coolant Pump Inlet Pressure & Temperature	Pressure & Temperature	3/4" -14 NPTF
6 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	1/4" -18 NPT
7 – Sea Water Return Temperature	Temperature	1/4" -18 NPT