



| Test Port/Connection | Measurement | Connection Type |
|---|------------------------|-----------------|
| 1 – Exhaust Back Pressure & Temperature | Pressure & Temperature | 1/8" -27 NPTF |
| 2 – Air Intake Restriction | Pressure | 1/8" -27 NPTF |
| 3 – Fuel Inlet Restriction | Pressure | M12 x 1.5 |
| 4 – Fuel Return Pressure & Temperature | Pressure & Temperature | 1/2" UNS 2B |
| 5 – Coolant Pump Inlet Pressure & Temperature | Pressure & Temperature | M18 x 1.5* |
| 6 – Sea Water Pump Inlet Pressure & Temperature | Pressure & Temperature | 1/4" -18 NPT |
| 7 – Sea Water Return Temperature | Temperature | 1/4" -18 NPTF |

* If port is utilized for coolant return this parameter cannot be checked. A port will be added to the coolant tube in the future to check this parameter.