



Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure and Temperature	Pressure & Temperature	1/8" -27 NPT
2 – Air Intake Restriction	Pressure	1/8" -27 NPT
3 – Fuel Inlet Restriction	Pressure	3/8" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	1/2" UNS 2B
5 – Coolant Pump Inlet Pressure & Temperature	Pressure & Temperature	No connection provided*
6 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	1/4" -18 NPT
7 – Sea Water Return Temperature	Temperature	1/2" -14 NPTF (anode location)

* A port will be added to the coolant tube in the future to check this parameter.