



Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure and Temperature	Pressure & Temperature	1/8" -27 NPT
2 – Air Intake Restriction	Pressure	1/8" -27 NPT
3 – Fuel Inlet Restriction	Pressure	3/8" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	1/8" -27 NPTF
5 – Coolant Pump Inlet Pressure & Temperature	Pressure & Temperature	M18 x 1.5*
6 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	Provide in vessel plumbing
7 – Sea Water Return Temperature	Temperature	½" -14 NPTF (anode location)

\* If port is utilized for coolant return this parameter cannot be checked. A port will be added to the coolant tube in the future to check this parameter.