



Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure & Temperature	Pressure & Temperature	1/8" -27 NPTF
2 – Air Intake Restriction	Pressure	1/8" -27 NPTF
3 – Fuel Inlet Restriction	Pressure	3/8" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	3/8" ORFS
5 – Coolant Pump Inlet Pressure & Temperature	Pressure & Temperature	No connection provided*
6 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	1/4" NPT
7 – Sea Water Return Temperature	Temperature	1/2" -14 NPTF

* A port will be added to the coolant elbow in the future to check this parameter.