



Test Port/Connection	Measurement	Connection Type
1 – Exhaust Back Pressure & Temperature	Pressure & Temperature	1/8" -27 NPTF
2 – Air Intake Restriction	Pressure & Temperature	1/8" -27 NPTF
3 – Fuel Inlet Restriction	Pressure	3/8" ORFS
4 – Fuel Return Pressure & Temperature	Pressure & Temperature	3/8" ORFS
5 – Coolant Pump Inlet Pressure	Pressure	M27 x 2*
6 – Sea Water Pump Inlet Pressure & Temperature	Pressure & Temperature	1/4" -18 NPT
7 – Sea Water Return Temperature	Temperature	1/2" -14 NPTF (anode location)

* If port is utilized for coolant return this parameter cannot be checked. A port will be added to the coolant elbow in the future to check this parameter.